

WIFI Printer IP Setting installation procedure

We should ensure following two points when we want to use the WIFI printer.

1: A valid IP address should be allocated to the printer.

2: Install the correct printer driver.

How to allocate a valid IP for WIFI printer ?

1. Find the file named “ HF-LPB100” by wireless network and link it.

2. Put the IP address (10.10.100.254) into the Web browser’s address bar, enter it we can see


below window:




User name : admin

Default password : admin

3, Select Work Mode : Select “AP+STA mode” , and save.



4, Select “ STA Setting ” as below;



4.1, Then click "Scan", it will appear selection as below:

中文 | English

Please select your current wireless network

Site Survey

	SSID	BSSID	RSSI	Channel
<input type="radio"/>	ChinaNet-iApS	D4:6E:5C:76:39:44	33	1
<input type="radio"/>	libo	C0:61:18:60:E5:64	0	1
<input type="radio"/>	WiFi-21	B0:D5:9D:2C:65:21	78	6
<input type="radio"/>		5C:63:BF:96:73:C	52	6
<input type="radio"/>	TP-LINK_E5977A	28:2C:B2:E5:97:7A	4	6
<input checked="" type="radio"/>	TP-LINK_F901D1	A8:57:4E:F9:1:D1	82	11
<input type="radio"/>	tianyuxin	EC:6C:9F:A:DE:C2	9	11
<input type="radio"/>	ChinaNet-Lb74	0:1E:40:F4:A2:78	11	11

OK Refresh

Above are all your current wireless network, select one of your wireless device available to be used, then click "OK".

4.2, Input the correct configuration as below, if setting is completed, click "Save".

中文 | English

Network Name (SSID)
Note: case sensitive

TP-LINK_F901D1 Scan

Encryption Method WPA2PSK

Encryption Algorithm AES

Password

Show passwords

Obtain an IP address automatically Disable

IP Address 192.168.1.105

Subnet Mask 255.255.255.0


Gateway Address 192.168.1.1

DNS Server Address 10.10.100.254


Save

IP should be set in the same network segment with the router, IP cannot be used by other devices.


5, Select "Other Setting", setting process are as below, after finishing, click " Save".



6, Restart the module, click "OK" , then the printer WIFI module configuration is finished.




7, Click the computer “Start” → “ Run” , Input the word “ cmd ” , as below:



```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [版本 5.1.2600]
(C) 版权所有 1985-2001 Microsoft Corp.
C:\Documents and Settings\Administrator>
```

Input “ ping 192.168.1.105 -t ” and if the details shows as below , means the connection is OK.



```
C:\WINDOWS\system32\cmd.exe - ping 192.168.1.105 -t
Microsoft Windows XP [版本 5.1.2600]
(C) 版权所有 1985-2001 Microsoft Corp.
C:\Documents and Settings\Administrator>ping 192.168.1.105 -t
Pinging 192.168.1.105 with 32 bytes of data:
Reply from 192.168.1.105: bytes=32 time=61ms TTL=255
Reply from 192.168.1.105: bytes=32 time=1ms TTL=255
Reply from 192.168.1.105: bytes=32 time=3ms TTL=255
Reply from 192.168.1.105: bytes=32 time=2ms TTL=255
Reply from 192.168.1.105: bytes=32 time=86ms TTL=255
Reply from 192.168.1.105: bytes=32 time=1ms TTL=255
Reply from 192.168.1.105: bytes=32 time=2ms TTL=255
Reply from 192.168.1.105: bytes=32 time=1ms TTL=255
```